

IDENTIFICATION OF FUSE BOX CIRCUITS

6.41. RIFF 8

<u>LEFT FUSE BOX MARKINGS</u>	<u>FUSE SIZE</u>	<u>POSITION</u>	<u>CIRCUIT</u>
Spineterogeni	16A	1	Ignition Coils
Avviamento	8A	2	Starter Solenoid
Avvis. - Accendisigari, Servizi	16A	3	Horn, Cigar Lighter, Acces.
Spiadinamo - Ind. Livello, Overdrive - Ventilator	8A	4	Gen. Lamp, Fuel Level Overdrive, Fan, Instruments
Tergicristallo - Electroflux, Illuminazione Quadro - Servizi	16A	5	Windshield Wipers, Electric Fuel Pump, Dash Lights, Acces.
Indicatori Direzione - Stop Condizionatore	16A	6	Stop and Turn Signals Air Conditioner

<u>RIGHT FUSE BOX MARKINGS</u>	<u>FUSE SIZE</u>	<u>POSITION</u>	<u>CIRCUIT</u>
Abbagliante - Dex.	8A	1	Right High Beam Lamp
Abbagliante - Sin.	8A	2	Left High Beam Lamp
Antiabbagliante - Dex.	8A	3	Right Low Beam Lamp
Antiabbagliante - Sin.	8A	4	Left Low Beam Lamp
Posizione - Targa, Cofano - Retromarcia	8A	5	Side Lamps, License Plate Lamp, Engine Comp. Lamp, Trunk & Back-up Lamps
Antinebbia, Plafoniere	8A	6	Fog Lamps, Interior Lamps.

RIFF-8